


# CHILDREN'S ELECTRONIC TOY CAR OPERATION INSTRUCTIONS

Please read a manual in detail before using



- Suitable for age 3+ years.
- Always wear helmet when riding.
- Your new vehicle requires adult assembly.
- Charging the battery can only be operated by adult all times.
- Please keep this manual for future reference as it contains.

**Have already implemented ISO9001:2000 authentication**

## Table of contents

1. About Our Product	-----
2. The Specification	-----
3. Parts	-----
4. CautinosFor Safety	-----
5. Parts Diagram	-----
6.Assembly Steps	-----
7. How To Operation The Vehicle	-----
8. Fuse	-----
9. Charging The Vehicle	-----
10. Trouble Shooting Guide	-----
11. Maintaining Your Vehicle	-----
12. Disposal Of Battery	-----

### 1.About Our Product:

Thank you for your purchasing our products, we always keep pursuing being outstanding and designing comfortable and safe ride-on car for children .it will provide your children a wonderful childhood and your family lots of happiness.


Please read the manuals carefully before using this product. You can get correct operation method, simple and detailed installation procedure. Moreover, it can instruct you how to prevent improper way of operation, because any incident can result in serious injury.

Please read it carefully to make sure that all children obey all warning, cautions, instructs and safety topics and assure young riders are able to safely use this product.


### 2.The Specification

Suitable age:	3+ Years	Battery:	6V 7AH *1
Load Capacity:	Under 30KGS	Size of car:	80*58*52CM
Speed:	3-5 KM/H	Power way:	Charging type
Charge:	Input: depend on local voltage Output: DC 6V500mA	Average battery life:	Approximately 300 times
Charge time:	8-12 Hours	Fuse	F 10A

### 3.Parts list



1.Vehicle Body X1



2.Handbar X1


3. Seat X1




4. Driving Wheel X1




5. Wheel X3




6. Hubcap X4




7. Rear Axle X1



8.Charger X1



9. Spanner X1



10. Accessory Package X1


## 4. Cautions for safety

1. While riding, adult supervision is required at all times.
2. Always wear a helmet when riding.
3. Do not drive near roads or on the footpath.
5. It is not recommended to ride this vehicle on sandy or soft surfaces.
4. It is not recommended to drive the vehicle on wet surfaces or on slopes of greater than 15 degrees.
6. Do not use this vehicle outdoors when it is raining.
7. Make sure you come to a complete stop before changing directions from forward to back.
8. Don't allow children to operate the charger or play with the battery.
9. Clean the vehicle with a dry cloth only.
10. Please follow the correct weight and age limits allowed to drive this vehicle.
11. It is prohibited to change the circuit or add other electric parts.
12. Adults must teach their children about safe driving procedures.
13. Please cut off the power when stop diving.
14. Check the seat. Whether it has been fitted and secured with a bolt before driving.
15. Inspect wires and connections of the vehicle periodically.
16. Charging the battery should only be done by adults.
17. Charging plug is located underneath the seat.  
Check all wire plugs and connections periodically.
18. In order to avoid accidents, please ensure the vehicle is safe before riding.
19. Do not let any child touch the wheels or be near them when the car is moving .

## 5. Assembly Steps


**NOTE:** some parts shown are assembled on both sides of vehicle.

①	Vehicle Body X1
②	Rear Axle X1
③	Driving Wheel X1
④	Hubcap X4
⑤	Ø10 Washers X7
⑥	Locknut X4
⑦	Wheel X3
⑧	Handbar X1
⑨	Seat X1




## 6. Assembly Steps

- Your new vehicle requires adult assembly. Please set aside at least 30 minutes for assembly. Children should not handle parts, or help in assembly of the vehicle.
- Please identify all parts before assembly and save all packaging material until assembly is complete to ensure that no parts are discarded.
- Assembly tool for need: screwdriver(not included ) and spanner.
- All the needed screws are packed in a small accessory package, then stuck on the parts which these screws to complete assembly.




### 1 Assemble rear axle

- Turn the vehicle body over.
- Screw off the locknut from the axle, take the Ø10 washer out (leave over one Ø10 washer).
- Slide the rear axle through the hole near the rear of vehicle from left side.




### 2 Assemble Driving Wheel

- Follow the steps of driving wheel, hubcap, Ø10 washer through the axle, fasten the locknut by spanner,
- Remember to follow the same steps for other two wheels



### 3 Assemble wheel

- Screw off the locknut from axle, take the washer out.
- Follow the steps of Ø10 washer, wheel, hubcap, Ø10 washer through the axle, fasten the locknut by spanner,
- Remember to follow the same steps for other two wheels




#### 4 Assemble the battery of the music

- Loosen the screw in the steering wheel remove the battery cover.
- Insert two “AA” (Lr6) alkaline batteries in the steering wheel. then close the battery cover and tighten the screw.
- (Please NOTE : the product does not provide alkaline battery )

#### Battery Safety Information


Batteries may leak fluids that can cause chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short-circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Use only batteries of the same or equivalent type as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.




#### 5 assemble handlebar

Turn the vehicle upright. Fit the handlebar steering column through the large opening in the front end of the vehicle. Lift the front end of the vehicle up slightly. Check to be sure the steering column fits through the hole in the steering linkage. Push down on the handlebar assembly to “snap” it in place.




### 7 Connect battery wires(1)

screw off the five screws from battery cover, remove it.



### 7 Connect battery wires(2)

Plug the power connector into battery terminal (red to red, black to black). Place the battery cover at the homologous position on the vehicle body. Insert five screws with a screwdriver.



### 8 Assembly seat

Fit the tabs on the front of the seat into the slots. Push down firmly near the back of the seat to "snap" it in the vehicle. (You will need to remove the seat to replace the fuse. To remove the seat, press the tabs at the back of the seat and lift.)



## 7. How To Operate The Vehicle


Make sure below works have been done before using:


- The vehicle was assembled well according to the instruction manual.
- Teach appropriate safety rules to your child before allowing operation of this vehicle. These rules should also be reviewed with neighborhood children or other playmates who want to drive this vehicle.

To reduce the risk of injury:

- Always wear a helmet when riding.
- Direct Adult Supervision Required.
- Always sit on the seat.
- Always Wears shoes.
- Never allow more than one rider.
- Keep Children within Safe Riding Areas:  
Never use in roadway, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water;
- Use the toy only on flat surfaces. such as inside your house, garden or playground.
- Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or a well-lit area.
- This vehicle has adjustable play seat belts. please instruct children how to tie the safety belt before using, guarantee the security.

Use operation (refer to the sketch map of function)






### FORWARD

1. turn on the power switch
2. Press the "Forward-backward switch" button on the "Forward".
3. Press the foot pedal.
4. The vehicle goes forward.




### STOP

1. The vehicle is equipped with the automatic brake device, when unclasp the pedal, the vehicle brakes automatically.



### BACKWARD

1. turn on the power switch
2. Press the "Forward-backward switch" button on the "backward".
3. Press the foot pedal.
4. The vehicle goes backward.



### SOUNDS BUTTON


1. Press the buttons on the handlebar for sound .
- (Hint: When sound becomes faint or there is not sound at all, it's time to change the batteries in the handlebar)

## NOTICE:

- Have to teach child, unclasp the pedal and wait until the car is stopping before changing the speed or direction ,
- Forbid suddenly changing forward and back during moving ,because do so will damage the vehicle or hurt the rider.

## 8. Fuse

When the motorcycle won't work or can not be charged, please check the fuse first and see whether it is burnt out. If the fuse is broken, please change the broken one with a new one, there is a spare fuse in the fuse package. The fuse in under battery cover(under seat)



Pay attention: fuse 10 A

To use the vehicle, follow these guidelines:

- DO NOT overload the, vehicle, Maximum weight allowed: 30KG.
- DO NOT tow any thing behind the vehicle.
- DO NOT drive up steep slopes.
- DO NOT drive into fixed objects, which may cause the wheels to spin, causing the motor to overheat.
- DO NOT drive in very hot weather, components may overheat.
- DO NOT allow water or other liquids to come in contact with the battery or other electric components.
- DO NOT tamper with the electric system. Doing so may create a short circuit, causing the fuse to trip.

## 9. Charging The Vehicle

- The charging socket is under the seat. You will need to remove the seat to charging the vehicle . To remove the seat, press the tabs at the back of the seat and lift.


Charging must cut off the power.

Before the first use, you should charge the battery for 8-10 hours. Do not

- recharge the battery for more than 20 hours to avoid overheating the charger.

When the vehicle runs slowly, recharge the battery.

After each use or once a month minimum recharge for 8 to 12 hours, 20 hours at most.



1 To remove the seat, press the tabs at the back of the seat and lift. Open the cover of the socket.

2 Plug the charger plug into the socket.

3 Plug the charger plug into a wall outlet. The battery will begin charging.

To recharge the battery:

Battery charging must be done by adults only. Never allow children to

- charge the battery. A child could be injured by the electricity involved in charging the battery.

- Do not short circuit the battery.
- The charger and the battery are not a toy. Do not allow children to play with the charger and the battery.
- Only use the battery and charger specified by the manufacturer.
- Do not mix different types of batteries. Do not mix old and new battery.
- Do not open the battery and charger.
- Always secure the battery with the bracket. Battery can fall out and injure a child if vehicle tips over,
- The battery must be handled by adults only. The battery is heavy and contains sulfuric acid (electrolyte). Dropping the battery could result in serious injury.
- Do not allow the battery to drain completely, recharge the battery after each use or once a month if not used regularly.
- Before charging the battery check for wear or damage to the battery, charge, the connectors and other parts. If any damage is found, charger should be repaired or replaced immediately. Do not use a damaged charger.
- It is normal for the adaptor to feel warm during charging, but if the charger feels very hot, stop charging and check the battery and adaptor.

## 10. Trouble Shooting Guide

Problem	Possible Cause
(1).The 6-Volt battery Will not recharge	<ol style="list-style-type: none"> <li>1.Motor connector or adapter connector is loose. Make sure the motor connector and the adapter connector is firmly plugged.</li> <li>2.The 6-volt battery will not recharge. Make sure the charger is plugged into a 240 V wall outlet and the power flow to the outlet is on.</li> <li>3.Charger is not plugged in. Make sure the charger is plugged into a 240V wall outlet and the power flow to the outlet is on.</li> <li>4.Check and replace fuse if necessary</li> </ol>
(2).The vehicle does not run	<ol style="list-style-type: none"> <li>1.The battery may be low on power. After each use, or once a month minimum, charge the battery for a "full" 10 hours. DO NOT leave the battery on the charger for more than 20 hours.</li> <li>2.Thermal fuse has tripped. Replace the tripped fuse by another spare one.</li> </ol>

<p>(2).The vehicle does not run</p>	<p>3.Wheel nuts are loose. Tighten the wheel nuts with a wrench.</p> <p>4.Motor connector or wires are loose. Make sure the motor connector is firmly plugged into the battery.</p> <p>5.Battery is dead. Have you properly maintained the battery according to the directions? Is the battery old? Your battery may need to be replaced.</p> <p>6.Electrical system is damaged. Water may have corroded the system, or loose dirt, gravel or sand might have jammed the switch. Check.</p> <p>7.Motor is damaged. The vehicle needs professional repair.</p>
<p>(3).The vehicle does not run very long.</p>	<p>1.Battery may be undercharged. You may not be charging the battery long enough. After each use, or once a month minimum, charge the battery for a "full" 10 hours. DO NOT leave the battery on the charger for more than 20 hours.</p> <p>2.Battery is old. The 6-volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery Should operate for one to three years. Replace the battery with a new 6-volt battery.</p>
<p>(4).Battery buzzes or gurgles when charging.</p>	<p>1.This is normal and not a cause for concern. It may also be silent when charging, which is also normal.</p>
<p>(5).The vehicle runs sluggishly or beeping occurs.</p>	<p>1.Battery needs recharging. After each use, or once a month minimum, charge the battery for a "full" 10 hours. DO NOT leave the battery on the charger for more than 20 hours. Low battery signal will sound when the battery is running low on power.</p> <p>2.Battery is old. The 6-volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery Should operate for one to three years. Replace the battery with a new 6-volt battery.</p> <p>3.Vehicle is overloaded. Maximum weight is 30 kg. DO NOT overload the vehicle. DO NOT tow anything behind the vehicle. ONLY one rider at a time.</p>

## 11. Maintaining Your Vehicle

- It is parents' responsibility to check main parts of the toy before using, Must regularly examine for potential hazard, such as the battery, charge, cable or cord, plug, screws and other parts and that in the event of such damage, the toy must not be use until that damage had been properly removed.
- Use some lube to lubricate the metal parts to avoid rust after use the vehicle for some times.
- Keep the toy in a upturned direction, do not overturn or incline it. Park the vehicle indoors .
- This toy should be kept away from fire. Keep the vehicle away from sources of heat, such as stoves and heaters. Plastic parts may melt. While charging, must far leave flammable articles, prevent fire from occurring.
- ADULTS ONLY: recharge the battery after each use. Recharge the battery at least once a month when the vehicle is not being used.
- The vehicle can be cleaned with a soft, dry cloth.
- DO NOT use chemical liquid to clean the plastic surface of the toy.
- DO NOT wash the vehicle with soap and water.
- DO NOT drive the vehicle in rainy or snowy weather. Water will damage the motor, electric system and battery.
- When not using, all the power should be cut off. all switch press to “stop” or “imprison”.
- Please do not change the structure of this product and circuit system by yourself. Repair and maintain should be done under the guidance of technical staff or professional personnel .
- Do not use the toy for other purpose except riding.

## 12. Disposal Of Battery

### Disposal of Battery



- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Do not dispose of your lead-acid battery in a fire. The battery may explode or leak.
- Do not dispose of a lead-acid battery in your regular, household trash. The incineration, land filling or mixing of sealed lead-acid batteries with household trash is prohibited by law.
- Return an exhausted battery to your local approved lead-acid battery recycle, such as a local seller of automotive batteries.
- Contact your local waste management officials for other information regarding the environmentally sound recycling and disposal of lead-acid batteries.